

# 19737 iPad Air 2-Wandhalter



**KÖNIG & MEYER**

Stands For Music

- Die neue Wandhalterung hat das iPad Air 2 / Pro 9.7 sicher und komfortabel im Griff
- Schnelles und müheloses Einrasten und Entnehmen des iPad in den Halter
- Mit 3 Befestigungsbohrungen fest und sicher an der Wand zu befestigen
- Stufenlos um 360° verdrehbar für horizontalen und vertikalen Einsatz
- Diese Drehbewegung lässt sich leicht ausführen, wobei ein selbstständiges Drehen verhindert wird

Vielen Dank, dass Sie sich für dieses Produkt entschieden haben. Diese Anleitung informiert Sie über alle wichtigen Schritte bei Aufbau und Handhabung. Wir empfehlen, sie auch für den späteren Gebrauch aufzubewahren.

## SICHERHEITSHINWEISE


- Das iPad sorgfältig in die Halteplatte einclippen und auf sicheren Sitz prüfen - beim Verdrehen umsichtig handhaben.
- Der Halter wird mit drei Schrauben an der Wand befestigt. **BEACHTEN:**
  - Ungeeignet sind Wände, die zu schwach sind oder hinter denen Strom- und Wasserleitungen oder dgl. verlegt sind. Ggf. einen qualifizierten Fachmann fragen.
  - Je nach Wandbeschaffenheit (Holz, Beton, Ziegel etc.) entsprechendes Montagematerial verwenden (nicht im Lieferumfang).
  - Vergewissern Sie sich, dass nach der Installation die Schrauben und Muttern fest angezogen sind und wiederholen Sie diese Prüfungen regelmäßig.

## WANDMONTAGE

Die Wandhalterung ist vollständig vormontiert und kann direkt an der Wand befestigt werden.

- Die drei Bohrungen der runden Wandplatte ausrichten:
  - nach optischen oder
  - praktischen Gesichtspunkten
- Bohrlöcher markieren
- Dübellöcher bohren
  - $\varnothing$  6 mm bei Kunststoffdübeln
  - ggf.  $\varnothing$  3 mm bei Holzschrauben
- Befestigungsbeispiel Steinwand
- Befestigungsbeispiel Holzwand

### WANDMONTAGE Befestigungsbeispiele




Bei Porenbeton, Gipskarton etc. empfehlen wir Ihnen sich im Fachhandel nach geeigneten Verankerungen zu erkundigen.

## BENUTZERHINWEISE


- AUSRICHTEN des iPad
- iPad nach dem HOME-Button-Symbol AUSRICHTEN (siehe Prägung auf der Halteplatte)

### AUSRICHTEN des iPad




- EINLEGEN des iPad
- iPad erst unten EINLEGEN...
  - ...danach oben EINCLIPSEN

### EINLEGEN des iPad



- ENTNEHMEN des iPad
- iPad festhalten und oberen Haken ANHEBEN
  - iPad herausklappen und ENTNEHMEN


### ENTNEHMEN des iPad



## FORMAT

- Die Halterung verfügt über eine 360°-Drehfunktion. Dadurch kann das iPad hochkant oder quer oder in jede andere gewünschte Position gebracht werden. Dabei kann das iPad in der Halterung verbleiben.

### FORMAT



## TECHNISCHE DATEN / SPEZIFIKATION

Material	Wandplatte: Polyamid (PA-6) Aufnahmeplatte: Polypropylen (PP) Schrauben, Muttern, Scheiben, Federn: Stahl
Traglast	iPad Air 2 oder iPad Pro 9.7
Maße	Aufstellmaß: 249 x 38 x 178,7 mm Karton: 300 x 102 x 230 mm
Gewicht	netto 0,14 kg, brutto 0,43 kg

Endstellung:  
- quer (landscape)  
- eingerastet

Zwischenposition:  
- schräg  
- nicht eingerastet, behält jedoch die gewählte Einstellung

Endstellung:  
- hoch (portrait)  
- eingerastet

### FEHLERSUCHE (F) und BESEITIGUNG (B)

F: Halterung wackelt B: Wandverschraubung prüfen

B: Verbindung Wandplatte-Aufnahmeplatte prüfen

F: iPad sitzt nicht richtig B: iPad korrekt einlegen und dabei hörbar einrasten lassen

# 19737 iPad Air 2 wall mount **K&M** KÖNIG & MEYER

Stands For Music

- **Securely Held in Place!** The best way to enjoy your iPad Air 2 / Pro 9.7
- **The iPad clicks into the holder quickly and effortlessly**
- **It is secured by 3 drill holes in the wall, ensuring a secure hold**
- **Can be rotated 360° - it can be positioned horizontally and vertically**
- **Rotating is easy, and your iPad Air stays securely in the position you select**

Thank you for choosing this product. The instructions provide directions to all of the important set up and handling steps. We recommend you keep these instructions for future reference.

## SAFETY NOTES


- Carefully clip the iPad onto the holding plate and ensure that the iPad fit is secure - be careful you when the iPad is positioned.
- The holder is affixed to the wall with three screws. ENSURE:
  - Walls, that are too weak or have electrical and water conduits are not suitable. If this is the case consult a qualified handyman.
  - Depending on the wall composition (Wood, Concrete, Bricks etc.) use the appropriate mounting materials (not included with the delivery)
  - Ensure that the screw and nuts are tight and check this routinely.

## WALL MOUNT

The wall mount comes fully assembled and can be mounted to the wall.

- The three drill holes are to be placed according to the round wall plate:
  - according to a good estimate
  - practical know how
- Mark the drill holes
- Drill the anchor holes
  - $\varnothing$  6 mm for plastic anchors
  - $\varnothing$  3 mm for wood anchors
- Mounting example concrete wall
- Mounting example wood wall

### WALL MOUNT mounting examples




If the wall is made of aerated concrete, plasterboard etc. we recommend that you consult a hardware store to purchase the suitable anchor materials.

## USAGE NOTES


### ORIENTATION of the iPad

- Place the iPad according to the HOME-Button-Symbol (consult the embossing on the holding plate).




### PLACEMENT of the iPad

- First PLACE the iPad into the bottom area and...
- ...then CLIP it into the top



### REMOVAL of the iPad


- Hold the iPad and LIFT the upper hook
- Hold the iPad and REMOVE it



### FORMAT

- The holder is equipped with a 360°-rotating function. The iPad can be placed in any desired position - vertical - horizontal and everywhere in between. The iPad does not have to be removed for the holder.

### FORMAT



## TECHNICAL DATA

Material	Swivel Bearing: Polyamid (PA-6) Holding Plate: Polypropylen (PP) Screws, nuts, washers, springs: steel
Max. load	iPad Air 2 or iPad Pro 9.7
Dimensions	Base dimensions: 249 x 38 x 178,7 mm Box: 300 x 102 x 230 mm
Weight	net 0.14 kg, gross 0.43 kg

- Final Position - landscape - click into place
- Incline Position - cannot be clicked into place, however it does stay in the selected position
- Final Position - portrait - click into place

### FAULT FINDING (F) and REPAIR (R)

- F: Holder is not stable B: Check the wall screws  
B: Check the connection between the wall plate and holder plate
- F: iPad is not firmly in place B: Place the iPad into the holder correctly (so you can hear the click)